



SUMNER PRIMARY fixing method is for C-Series and D-Series (75kg/m²). Maximum 220mm centers. Horizontal screws start 33mm from perimeter, vertical screws 100mm from perimeter.

SUMNER HEAVY WEIGHT fixing method is for Urban Series (100kg/m²), and must be screwed off at centers NO greater than 180mm.

Fixing centers only apply to Sumner Board, high density fiber cement sheeting for stone veneer.

Do NOT countersink screws. Instead leave them 1 - 2 mm proud.

SUMNER BATTENS

Vertical 2lm battens are fixed at 600mm centers. If less than 400mm you can purchase more
Horizontal 1lm battens are set at 800mm vertical centers.

06

Sumner Board Fixing Detail

SCALE

NTS

DATE

NOVEMBER 2011



SUMNER
ORIGINAL STONE CO. LTD.

Original Stone Co Ltd
PO Box 125 029, St Helens
Auckland 0800 157 340